

This Product MasterSpec Section is licensed by AVITRU, LLC to ALUCOBOND®; 3A Composites USA Inc. ("Licensee").

This Product MasterSpec Section modifies the original MasterSpec text and does not include the full content of the original MasterSpec Section.

Revisions made to the original MasterSpec text are made solely by the Licensee and are not endorsed by, or representative of the opinions of, Avitru or The American Institute of Architects (AIA). Neither AIA nor Avitru are liable in any way for such revisions or for the use of this Product MasterSpec Section by any end user. A qualified design professional should review and edit the document to suit project requirements.

For more information, contact ALUCOBOND®; 3A Composites USA Inc., 721 Jetton St., Ste 325, Davidson, NC 28036; Phone: (800) 626-3365; Website: www.3acomposites.com | www.alucobondusa.com; Email: info@3acomposites.com.

For information about MasterSpec, contact Avitru at (800) 424-5080 or visit avitru.com.

SECTION 074213.23 - METAL COMPOSITE MATERIAL WALL PANELS

TIPS:

To view non-printing **Editor's Notes** that provide guidance for editing, click on MasterWorks/Single-File Formatting/Toggle/Editor's Notes.

To read **detailed research, technical information about products and materials, and coordination checklists**, click on MasterWorks/Supporting Information.

Access Product MasterSpec Sections:

[<Double click here to view the list of manufacturer Sections available at ProductMasterSpec.com.>](#)

PART 1 - GENERAL

1.1 RELATED DOCUMENTS

- A. Drawings and general provisions of the Contract, including General and Supplementary Conditions and Division 01 Specification Sections, apply to this Section.

1.2 SUMMARY

- A. Section includes MCM wall panels.

1.3 DEFINITIONS

- A. DBVR: Drained and back-ventilated rainscreen system; rainscreen system designed to drain and dry cavity entering water through drainage channels, weeps, and air ventilation.
- B. MCM: MCM; cladding material formed by joining two thin metal skins to polyethylene or fire-retardant core and bonded under precise temperature, pressure, and tension.
- C. PER: Pressure equalized rainscreen system; rainscreen system designed for no water intrusion with equal pressure between interior system cavity and outside cladding barrier.

1.4 PREINSTALLATION MEETINGS

- A. Preinstallation Conference: Conduct conference at **[Project site]** <Insert location>.
 - 1. Meet with Owner, Architect, Owner's insurer if applicable, MCM panel Fabricator and Installer, MCM sheet manufacturer's representative, structural-support Installer, and installers whose work interfaces with or affects MCM panels, including installers of doors, windows, and louvers.
 - 2. Review and finalize construction schedule and verify availability of materials, Installer's personnel, equipment, and facilities needed to make progress and avoid delays.
 - 3. Review methods and procedures related to MCM panel installation, including manufacturer's written instructions.
 - 4. Examine support conditions for compliance with requirements, including alignment between and attachment to structural members.
 - 5. Review flashings, special siding details, wall penetrations, openings, and condition of other construction that affect MCM panels.
 - 6. Review governing regulations and requirements for insurance, certificates, and tests and inspections if applicable.
 - 7. Review temporary protection requirements for MCM panel assembly during and after installation.
 - 8. Review procedures for repair of panels damaged after installation.
 - 9. Document proceedings, including corrective measures and actions required, and furnish copy of record to each participant.

1.5 ACTION SUBMITTALS

- A. Product Data: For each type of product.
 - 1. Include construction details, material descriptions, dimensions of individual components and profiles, and finishes for each type of panel and accessory.
- B. Shop Drawings:
 - 1. Include fabrication and installation layouts of MCM panels; details of edge conditions, joints, panel profiles, corners, anchorages, attachment assembly, trim, flashings, closures, and accessories; and special details.

2. Accessories: Include details of the flashing, trim and anchorage, at a scale of not less than **1-1/2 inches per 12 inches (1:10)**.
- C. Samples for Initial Selection: For each type of MCM panel indicated with factory-applied color finishes.
 1. Include similar Samples of trim and accessories involving color selection.
- D. Samples for Verification: For each type of exposed finish required, prepared on Samples of size indicated below.
 1. MCM Panels: **12 inches (305 mm)** long by actual panel width. Include fasteners, closures, and other MCM panel accessories. Submit custom color samples in paint manufacturer's standard size.

1.6 INFORMATIONAL SUBMITTALS

- A. Qualification Data: For Installer.
- B. Product Test Reports: For each product, tests performed by a qualified testing agency.
 1. MCM Manufacturer's Material Test Reports: Certified test reports showing compliance with specific performance or third-party listing documenting compliance to comparable code sections IBC 1407.14 and IBC 1703.5.
 2. MCM System Fabricator's Certified System Tests Reports: Certified system test reports showing system compliance with specific performance or third-party listing documenting compliance code section. Base performance requirements on MCM system type provided.
 - a. Wet System: Tested to AAMA 501.
 - b. Dry System: Tested to AAMA 501.
 - c. DBVR System: Tested to AAMA 509.
 - d. PER System: Tested to AAMA 508.
- C. Field quality-control reports.
- D. Sample Warranties: For special warranties.

1.7 CLOSEOUT SUBMITTALS

- A. Maintenance Data: For MCM panels to include in maintenance manuals.

1.8 QUALITY ASSURANCE

- A. Installer Qualifications: An entity that employs installers and supervisors who are trained and approved by MCM Fabricator.

- B. Mockups: Build mockups to verify selections made under Sample submittals and to demonstrate aesthetic effects and set quality standards for MCM fabrication and installation.
 - 1. Build mockup of typical MCM panel assembly [**as shown on Drawings**] <Insert size>, including [**corner,**] [**soffits,**] supports, attachments, and accessories.
 - 2. Water-Spray Test: Conduct water-spray test of mockup of MCM panel assembly, testing for water penetration in accordance with AAMA 501.2.
 - 3. Approval of mockups does not constitute approval of deviations from the Contract Documents contained in mockups unless Architect specifically approves such deviations in writing.
 - 4. Subject to compliance with requirements, approved mockups may become part of the completed Work if undisturbed at time of Substantial Completion.

1.9 DELIVERY, STORAGE, AND HANDLING

- A. Deliver components, MCM panels, and other manufactured items so as not to be damaged or deformed. Package MCM panels for protection during transportation and handling.
- B. Unload, store, and erect MCM panels in a manner to prevent bending, warping, twisting, and surface damage.
- C. Stack MCM panels on platforms or pallets, covered with suitable weathertight and ventilated covering. Store MCM panels to ensure dryness, with positive slope for drainage of water. Do not store MCM panels in contact with other materials that might cause staining, denting, or other surface damage.
- D. Retain strippable protective covering on MCM panels during installation.

1.10 FIELD CONDITIONS

- A. Weather Limitations: Proceed with installation only when existing and forecasted weather conditions permit assembly of MCM panels to be performed in accordance with manufacturers' written instructions and warranty requirements.

1.11 COORDINATION

- A. Coordinate MCM panel installation with rain drainage work, flashing, trim, construction of soffits, and other adjoining work to provide a leakproof, secure, and noncorrosive installation.

1.12 WARRANTY

- A. Warranty on Panel Material: Manufacturer's standard form in which manufacturer agrees to replace MCM that fails within specified warranty period.
 - 1. Warranty Period: Five years from date of Substantial Completion.

- B. Special Warranty on Panel Finishes: Manufacturer's standard form in which manufacturer agrees to repair finish or replace MCM panels that show evidence of deterioration of factory-applied finishes within specified warranty period.
1. Finish Warranty Period: **[20]** **[10]** **[Five]** years from date of Substantial Completion.

PART 2 - PRODUCTS

2.1 PERFORMANCE REQUIREMENTS

- A. Structural Performance: Provide MCM panel systems capable of withstanding the effects of the following loads, based on testing in accordance with ASTM E330:
1. Wind Loads: As indicated on Drawings.
 2. Other Design Loads: **[As indicated on Drawings]** **<Insert loads>**.
 3. Deflection Limits: For wind loads, no greater than **[1/180]** **[1/240]** **<Insert deflection>** of the span.
 4. **<Insert serviceability requirements>**.
- B. Air Infiltration: Air leakage of not more than **0.06 cfm/sq. ft. (0.3 L/s per sq. m)** of wall area when tested in accordance with ASTM E283 at the following test-pressure difference:
1. Test-Pressure Difference: **6.24 lbf/sq. ft. (300 Pa)**.
- C. Water Penetration under Static Pressure: No water penetration to room side of assembly when tested for 15 minutes in accordance with ASTM E331 at the following test-pressure difference:
1. Test-Pressure Difference: **6.24 lbf/sq. ft. (300 Pa)**.
- D. Thermal Movements: Locate expansion and contraction points to allow for free and noiseless thermal movements from surface temperature changes.
1. Temperature Change (Range): **minus 20 deg F to 180 deg F (minus 29 to 82.2 deg C)**, material surfaces.
- E. Fire Propagation Characteristics: MCM wall assembly passes NFPA 285 testing.

2.2 MCM WALL PANELS **<Insert drawing designation>**

- A. MCM Wall Panel Systems: Provide factory-formed and -assembled, MCM wall panels fabricated from two metal facings that are bonded to a solid, extruded thermoplastic core; formed into profile for installation method indicated. Include attachment assembly components[, **panel stiffeners**], and accessories required for weathertight system.
1. Basis-of-Design Product: Subject to compliance with requirements, provide ALUCOBOND®; 3A Composites USA Inc.; ALUCOBOND® PLUS or comparable product by one of the following:

- a. Arconic Architectural Products (USA).
 - b. Mitsubishi Chemical Composites.
 - c. <Insert manufacturer's name>.
- B. Aluminum-Faced Composite Wall Panels <Insert drawing designation>: Formed with **0.020-inch- (0.50-mm-)** thick, [**coil-coated**] [**anodized**] aluminum sheet facings.
1. Panel Thickness: [**0.157 inch (4 mm)**] [As indicated on Drawings].
 2. Core: [**Standard**] [**Fire retardant**].
 3. Exterior Finish: [**PVDF fluoropolymer**] [**FEVE fluoropolymer**] [**Siliconized polyester**] [**Clear anodized**] [**Color anodized**].
 - a. Color: [As indicated by manufacturer's designations] [As selected by Architect from manufacturer's full range] [As indicated on drawing schedule].
 - 1) Color 1: <Insert color>.
 - 2) Color 2: <Insert color>.
 - 3) Color 3: <Insert color>.
 - 4) Color 4: <Insert color>.
 4. Peel Strength: **22.5 in-lb/in. (100 N x mm/mm)** when tested for bond integrity in accordance with ASTM D1781.
 5. Fire Performance: Flame spread less than 25 and smoke developed less than 450, in accordance with ASTM E84.
- C. Attachment Assembly Components: Formed from [**extruded aluminum**] [**material compatible with panel facing**].

2.3 MISCELLANEOUS MATERIALS

- A. Miscellaneous Metal Subframing and Furring: ASTM C645, cold-formed, metallic-coated steel sheet ASTM A653/A653M, **G90 (Z275 hot-dip galvanized)** coating designation or ASTM A792/A792M, **Class AZ50 (Class AZM150)** aluminum-zinc-alloy coating designation unless otherwise indicated. Provide Fabricator's standard sections as required for support and alignment of MCM panel system.
- B. Panel Accessories: Provide components required for a complete, weathertight panel system including trim, copings, fasciae, mullions, sills, corner units, clips, flashings, sealants, gaskets, fillers, closure strips, and similar items. Match material and finish of MCM panels unless otherwise indicated.
- C. Flashing and Trim: Provide flashing and trim formed from same material as MCM panels as required to seal against weather and to provide finished appearance. Locations include, but are not limited to, bases, drips, sills, jambs, corners, endwalls, framed openings, rakes, fasciae, parapet caps, soffits, reveals, and fillers. Finish flashing and trim with same finish system as adjacent MCM panels.

1. Basis-of-Design Product: Subject to compliance with requirements, provide ALUCOBOND®; 3A Composites USA Inc.; ALUCOBOND® Axcent™ Trim or comparable product by one of the following:
 - a. Arconic Architectural Products (USA).
 - b. Mitsubishi Chemical Composites.
 - c. **<Insert manufacturer's name>**.
 2. Aluminum Trim: Formed with **0.040-inch (1.00-mm-)** thick, coil-coated aluminum sheet facings.
 3. Color: **[As indicated by manufacturer's designations] [As selected by Architect from manufacturer's full range] [As indicated on drawing schedule]**.
 - a. Color 1: **<Insert color>**.
 - b. Color 2: **<Insert color>**.
 - c. Color 3: **<Insert color>**.
 - d. Color 4: **<Insert color>**.
- D. Panel Fasteners: Self-tapping screws designed to withstand design loads. Provide exposed fasteners with heads matching color of MCM panels by means of plastic caps or factory-applied coating. Provide EPDM or PVC sealing washers for exposed fasteners.
- E. Panel Sealants: ASTM C920; elastomeric polyurethane or silicone sealant; of type, grade, class, and use classifications required to seal joints in MCM panels and remain weathertight; and as recommended in writing by MCM panel manufacturer.

2.4 FABRICATION

- A. General: Fabricate and finish MCM panels and accessories at the factory, by manufacturer's standard procedures and processes, as necessary to fulfill indicated performance requirements demonstrated by laboratory testing. Comply with indicated profiles and with dimensional and structural requirements.
- B. Fabricate MCM panel joints with factory-installed captive gaskets or separator strips that provide a weathertight seal and prevent metal-to-metal contact, and that minimize noise from movements.
- C. Sheet Metal Flashing and Trim: Fabricate flashing and trim to comply with manufacturer's recommendations or recommendations in SMACNA's "Architectural Sheet Metal Manual" that apply to design, dimensions, metal, and other characteristics of item indicated.
 1. Form exposed sheet metal accessories that are without excessive oil canning, buckling, and tool marks and that are true to line and levels indicated, with exposed edges folded back to form hems.
 2. Seams for Aluminum: Fabricate nonmoving seams with flat-lock seams. Form seams and seal with epoxy seam sealer. Rivet joints for additional strength.
 3. Seams for Other Than Aluminum: Fabricate nonmoving seams in accessories with flat-lock seams. Tin edges to be seamed, form seams, and solder.

4. Sealed Joints: Form non-expansion, but movable, joints in metal to accommodate sealant and to comply with SMACNA standards.
5. Conceal fasteners and expansion provisions where possible. Exposed fasteners are not allowed on faces of accessories exposed to view.
6. Fabricate cleats and attachment devices from same material as accessory being anchored or from compatible, noncorrosive metal recommended in writing by metal panel manufacturer.
 - a. Size: As recommended by SMACNA's "Architectural Sheet Metal Manual" or metal wall panel manufacturer for application but not less than thickness of metal being secured.

2.5 FINISHES

- A. Protect mechanical and painted finishes on exposed surfaces from damage by applying a strippable, temporary protective covering before shipping.
- B. Appearance of Finished Work: Variations in appearance of abutting or adjacent pieces are acceptable if they are within one-half of the range of approved Samples. Noticeable variations in same piece are not acceptable. Variations in appearance of other components are acceptable if they are within the range of approved Samples and are assembled or installed to minimize contrast.
- C. Aluminum Panels and Accessories:
 1. PVDF Fluoropolymer: AAMA 2605. Fluoropolymer finish containing not less than 70 percent PVDF resin by weight in color coat. Prepare, pretreat, and apply coating to exposed metal surfaces to comply with coating and resin manufacturers' written instructions.
 2. FEVE Fluoropolymer: AAMA 2605. One-coat [**clear**] [**tinted**] fluoropolymer finish containing 100 percent fluorinated ethylene vinyl ether resin in color coat. Prepare, pretreat, and apply coating to exposed metal surfaces to comply with coating and resin manufacturers' written instructions.
 3. Siliconized Polyester: Epoxy primer and silicone-modified, polyester-enamel topcoat; with a dry film thickness of not less than **0.2 mil (0.005 mm)** for primer and **0.8 mil (0.02 mm)** for topcoat.
 4. Exposed Anodized Finish:
 - a. Clear Anodic Finish: AAMA 611, AA-M12C22A41, Class I, 0.018 mm or thicker.
 - b. Color Anodic Finish: AAMA 611, AA-M12C22A42/A44, Class I, 0.018 mm or thicker.

PART 3 - EXECUTION

3.1 EXAMINATION

- A. Examine substrates, areas, and conditions, with Installer present, for compliance with requirements for installation tolerances, MCM panel supports, and other conditions affecting performance of the Work.
 - 1. Examine wall framing to verify that girts, angles, channels, studs, and other structural panel support members and anchorage have been installed within alignment tolerances required by MCM wall panel manufacturer.
 - 2. Examine wall sheathing to verify that sheathing joints are supported by framing or blocking and that installation is within flatness tolerances required by MCM wall panel manufacturer.
 - a. Verify that air- or water-resistive barriers have been installed over sheathing or backing substrate to prevent air infiltration or water penetration.
- B. Examine roughing-in for components and assemblies penetrating MCM panels to verify actual locations of penetrations relative to seam locations of MCM panels before installation.
- C. Proceed with installation only after unsatisfactory conditions have been corrected.

3.2 PREPARATION

- A. Miscellaneous Supports: Install subframing, furring, and other miscellaneous panel support members and anchorages in accordance with ASTM C754 and MCM panel manufacturer's written recommendations.

3.3 MCM PANEL INSTALLATION

- A. General: Install MCM panels in accordance with Fabricator's written instructions in orientation, sizes, and locations indicated on Drawings. Install panels perpendicular to supports unless otherwise indicated. Anchor MCM panels and other components of the Work securely in place, with provisions for thermal and structural movement.
 - 1. Shim or otherwise plumb substrates receiving MCM panels.
 - 2. Flash and seal MCM panels at perimeter of all openings. Fasten with self-tapping screws. Do not begin installation until air- or water-resistive barriers and flashings that will be concealed by MCM panels are installed.
 - 3. Install screw fasteners in predrilled holes.
 - 4. Locate and space fastenings in uniform vertical and horizontal alignment.
 - 5. Install flashing and trim as MCM panel work proceeds.
 - 6. Locate panel splices over, but not attached to, structural supports. Stagger panel splices and end laps to avoid a four-panel lap splice condition.
 - 7. Align bottoms of MCM panels and fasten with blind rivets, bolts, or self-tapping screws. Fasten flashings and trim around openings and similar elements with self-tapping screws.

8. Provide weathertight escutcheons for pipe- and conduit-penetrating panels.
- B. Fasteners:
1. Aluminum Panels: Use aluminum or stainless steel fasteners for surfaces exposed to the exterior; use aluminum or galvanized-steel fasteners for surfaces exposed to the interior.
- C. Metal Protection: Where dissimilar metals contact each other or corrosive substrates, protect against galvanic action as recommended in writing by MCM panel manufacturer.
- D. Attachment Assembly, General: Install attachment assembly required to support MCM wall panels and to provide a complete weathertight wall system, including subgirts, perimeter extrusions, tracks, drainage channels, panel clips, and anchor channels.
1. Include attachment to supports, panel-to-panel joinery, panel-to-dissimilar-material joinery, and panel-system joint seals.
- E. Panel Installation: Attach MCM wall panels to supports at locations, spacings, and with fasteners recommended by Fabricator to achieve performance requirements specified.
1. Wet Seal Systems: Seal horizontal and vertical joints between adjacent MCM wall panels with sealant backing and sealant. Install sealant backing and sealant in accordance with requirements specified in Section 079200 "Joint Sealants."
 - a. Clip Installation: Attach panel clips to supports at locations, spacings, and with fasteners recommended in writing by Fabricator. Attach routed-and-turned flanges of wall panels to panel clips with Fabricator's standard fasteners.
 - b. Panel Installation:
 - 1) Seal horizontal and vertical joints between adjacent panels with sealant backing and sealant. Install sealant backing and sealant in accordance with requirements specified in Section 079200 "Joint Sealants."
 - 2) Seal horizontal and vertical joints between adjacent MCM wall panels with Fabricator's standard gaskets.
 - c. Joint Sealing: Seal all joints in accordance with AAMA 501.
 2. Dry Seal Systems: Seal horizontal and vertical joints between adjacent MCM wall panels with Fabricator's standard gasket system.
 - a. Track-Support Installation: Install support assembly at locations, spacings, and with fasteners recommended by Fabricator. Use Fabricator's standard horizontal tracks and vertical [**tracks**] [**drain channels**] that provide support and secondary drainage assembly, draining to exterior at horizontal joints through drain tube. Attach MCM wall panels to tracks by interlocking panel edges with Fabricator's standard "T" clips.
 - b. Panel Installation:
 - 1) Attach routed-and-turned flanges of wall panels to perimeter extrusions with manufacturer's standard fasteners.

- 2) Install wall panels to allow individual panels to "free float" and be installed and removed without disturbing adjacent panels.
- c. Joint Sealing: Seal all joints in accordance with AAMA 501.
- F. PER Installation: Install using Fabricator's standard assembly with vertical channel that provides support and secondary drainage assembly, draining at base of wall. Notch vertical channel to receive support pins. Install vertical channels supported by channel brackets or adjuster angles and at locations, spacings, and with fasteners recommended by manufacturer. Attach MCM wall panels by inserting horizontal support pins into notches in vertical channels and into flanges of panels. Leave horizontal and vertical joints with open reveal.
1. Track-Support Installation: Install support assembly at locations, spacings, and with fasteners recommended by Fabricator. Use Fabricator's standard horizontal tracks and vertical [**tracks**] [**drain channels**] that provide support and secondary drainage assembly, draining to the exterior at horizontal joints through drain tube. Attach MCM wall panels to tracks by interlocking panel edges with Fabricator's standard "T" clips.
 2. Panel Installation:
 - a. Attach routed-and-returned flanges of wall panels to perimeter extrusions with Fabricator's standard fasteners.
 - b. Install wall panels to allow individual panels to "free float" and be installed and removed without disturbing adjacent panels.
 3. Joint Sealing: Seal all joints in accordance with AAMA 508. Do not apply sealants to joints unless indicated.
- G. DBVR System: Install using Fabricator's standard assembly with vertical channel that provides support and secondary drainage assembly, draining at base of wall. Notch vertical channel to receive support pins. Install vertical channels supported by channel brackets or adjuster angles and at locations, spacings, and with fasteners recommended by Fabricator. Attach MCM wall panels by inserting horizontal support pins into notches in vertical channels and into flanges of panels. Leave horizontal and vertical joints with open reveal.
1. Track-Support Installation: Install support assembly at locations, spacings, and with fasteners recommended by manufacturer. Use Fabricator's standard horizontal tracks and vertical [**tracks**] [**drain channels**] that provide support and secondary drainage assembly, draining to the exterior at horizontal joints through drain tube. Attach MCM wall panels to tracks by interlocking panel edges with Fabricator's standard "T" clips.
 2. Panel Installation:
 - a. Attach routed-and-returned flanges of wall panels to perimeter extrusions with manufacturer's standard fasteners.
 - b. Install wall panels to allow individual panels to "free float" and be installed and removed without disturbing adjacent panels.
 3. Joint Sealing: Seal all joints in accordance with AAMA 509. Do not apply sealants to joints unless otherwise indicated.

- H. Accessory Installation: Install accessories with positive anchorage to building and weathertight mounting, and provide for thermal expansion. Coordinate installation with flashings and other components.
1. Install components required for a complete MCM panel assembly including trim, copings, corners, seam covers, flashings, sealants, gaskets, fillers, closure strips, and similar items. Provide types indicated by MCM panel Fabricator; or, if not indicated, provide types recommended in writing by MCM system Fabricator.
- I. Flashing and Trim: Comply with performance requirements, manufacturer's written installation instructions, or SMACNA's "Architectural Sheet Metal Manual." Provide concealed fasteners where possible, and set units true to line and level as indicated. Install work with laps, joints, and seams that are permanently watertight.
1. Install exposed flashing and trim that is without buckling and tool marks and that is true to line and levels indicated, with exposed edges folded back to form hems. Install sheet metal flashing and trim to fit substrates and to result in waterproof performance.
 2. Expansion Provisions: Provide for thermal expansion of exposed flashing and trim. Space movement joints at a maximum of **10 feet (3 m)** with no joints allowed within **24 inches (605 mm)** of corner or intersection. Where lapped expansion provisions cannot be used or would not be sufficiently waterproof, form expansion joints of intermeshing hooked flanges, not less than **1 inch (25 mm)** deep, filled with mastic sealant (concealed within joints).

3.4 ERECTION TOLERANCES

A. Site Verifications of Conditions:

1. Verify conditions of substrate previously installed under other Sections are acceptable for the MCM system installation. Provide documentation indicating detrimental conditions to the MCM system performance.
2. Once conditions are verified, MCM system installation tolerances are as follows:
 - a. Shim and align MCM wall panel units within installed tolerance of **1/4 inch in 20 feet (6 mm in 6 m)**, non-accumulative, on level, plumb, and location lines as indicated, and within **1/8-inch (3-mm)** offset of adjoining faces and of alignment of matching profiles.

3.5 FIELD QUALITY CONTROL

- A. Testing Agency: [**Owner will engage**] [**Engage**] a qualified independent testing agency to perform field tests and inspections.
- B. Water-Spray Test: After installation, test area of assembly [**shown on Drawings**] [**as directed by Architect**] <Insert area> for water penetration in accordance with AAMA 501.2.
- C. Fabricator's Field Service: Engage a factory-authorized service representative to test and inspect completed MCM wall panel installation, including accessories.

- D. MCM wall panels will be considered defective if they do not pass test and inspections.
- E. Additional tests and inspections, at Contractor's expense, are performed to determine compliance of replaced or additional work with specified requirements.
- F. Prepare test and inspection reports.

3.6 CLEANING AND PROTECTION

- A. Remove temporary protective coverings and strippable films, if any, as MCM panels are installed, unless otherwise indicated in manufacturer's written installation instructions. On completion of MCM panel installation, clean finished surfaces as recommended by MCM panel manufacturer. Maintain in a clean condition during construction.
- B. After MCM panel installation, clear weep holes and drainage channels of obstructions, dirt, and sealant.
- C. Replace MCM panels that have been damaged or have deteriorated beyond successful repair by finish touchup or similar minor repair procedures.

END OF SECTION 074213.23